


INFRARED HEATING SYSTEM



SUPERIOR
RADIANT PRODUCTS

PREMIER VS-VH



WARNING

Improper installation, adjustment, alteration, service, or maintenance can cause property damage, injury or death. Read the installation, operation, and service instructions thoroughly before installing or servicing this equipment.

FOR YOUR SAFETY

Do not store or use flammable vapors and liquids in the vicinity of this or any other appliance.

If you smell gas:

1. Open windows
2. Don't touch electrical switches
3. Extinguish any open flame
4. Immediately call your gas supplier

OWNER

Retain this Manual and ensure available for service. Improper installation, adjustment, alteration, service, or maintenance can cause injury, death or property damage. Read the installation, operation, and service instructions thoroughly before installing or servicing this equipment

INSTALLER

Provide Manual to Owner upon completion of installation!

Read and thoroughly understand these Instructions before attempting any installation

Canada: 563 Barton Street, Stoney Creek, Ontario L8E 5S1

USA: 315 N Madison Street, Fortville, IN 46040

www.superiorradiant.com

CAUTION: FIRE OR EXPLOSION HAZARD

Maintain clearance to combustible materials as further specified in this manual. Failure to do so could result in a serious fire hazard. Heaters should not be located in hazardous atmospheres containing flammable vapors or combustible dusts. Signs should be provided in storage areas specifying maximum safe stacking height and safe parking locations for vehicles of various heights.

CAUTION: MECHANICAL HAZARD

This equipment expands and contracts with each operating cycle. The gas connection, suspension hardware, and the installation itself must safely allow this movement. Failure to do so could result in serious fire or explosion hazard.

CAUTION: FIRE OR EXPLOSION HAZARD

This heater is equipped with an automatic ignition device. Do not attempt to light the burner by hand. Failure to comply could result in a serious fire and personal injury hazard.

CAUTION: MECHANICAL HAZARD

Do not use high pressure (above ½ psi [3.5 kPa]) to test the gas supply system with the burners connected. Failure to comply could result in damage to the burner and its control components requiring replacement.

CAUTION: SERVICE LIFE RISK

Do not install equipment in atmospheres containing halogenated hydrocarbons or other corrosive chemicals. Failure to comply may lead to premature equipment failure and invalidation of the warranty. Additionally, it is recommended that the equipment be installed with a slope downward and away from the burner of ¼" in 10 ft (7 mm per 3 m) to allow drainage of start-up condensate.

CONTENTS

INTRODUCTION.....	5
OPERATING PRINCIPLE.....	5
APPLICABLE CODES	6
EQUIPMENT SPECIFICATIONS.....	7
SYSTEM LAYOUT TYPES.....	7
BASIC COMPONENTS.....	9
BURNERS	11
<i>Premier VS-VH - Chart of Burner Rates</i>	<i>13</i>
VACUUM PUMP A	14
VACUUM PUMP B	15
CLEARANCE TO COMBUSTIBLES	16
INSTALLATION.....	18
PREPARATION	18
LAYOUT LIMITS	18
ASSEMBLY OVERVIEW NOTES	20
1. RADIANT LINE SYSTEM	20
<i>A - Radiant Line Tubes</i>	<i>21</i>
<i>B - Tailpipe Tubes</i>	<i>24</i>
<i>C – Burners</i>	<i>25</i>
<i>D - Reflectors.....</i>	<i>29</i>
<i>E - Optional Shield Equipment</i>	<i>32</i>
<i>F - Deco-Grille Option.....</i>	<i>36</i>
2. VACUUM PUMP AND VENTING	37
<i>Vacuum Pump.....</i>	<i>37</i>
<i>Vacuum Pump Mounting</i>	<i>37</i>
<i>Venting.....</i>	<i>39</i>
<i>Ventilation Connections.....</i>	<i>40</i>
<i>Additional Pump Connections and Equipment.....</i>	<i>41</i>
3. OPTIONAL COMBUSTION AIR SUPPLY	42
<i>Combustion Air Supply Duct Connections</i>	<i>42</i>
4. GAS SUPPLY SYSTEM	43
<i>General Requirements</i>	<i>43</i>
<i>Flexible Gas Connector Line</i>	<i>44</i>
5. ELECTRICAL CONNECTIONS.....	45
<i>General Requirements</i>	<i>45</i>
<i>System Wiring Connections</i>	<i>47</i>
COMMISSIONING.....	52
1 - INSTALLATION CHECKLIST	53
2 - INITIAL SYSTEM POWER TEST	54
3 – COLD BALANCING THE SYSTEM VACUUM.....	54
OPERATION.....	56
MANUAL SET-UP	60
AUTOMATIC OPERATING SEQUENCE.....	60
<i>Start-up.....</i>	<i>60</i>
<i>Shut-down.....</i>	<i>60</i>
MAINTENANCE	61

GENERAL SAFETY REMINDERS	61
ANNUAL MAINTENANCE RECOMMENDATIONS	61
<i>The System</i>	61
<i>Each Burner</i>	61
<i>Adjust the System</i>	61
<i>Burner adjustment</i>	62
TROUBLE-SHOOTING	63
VACUUM PUMP	63
BURNERS	63
PARTS	64
WARRANTY	68

INTRODUCTION

Superior Radiant Products is a company in the infrared heating industry founded on the principles of product quality and consumer commitment.

Quality commitment is evidenced by superior design, a regard for design detail and an upgrade of materials wherever justifiable.

Customer commitment is apparent through our ready responses to market demands and a never-ending training and service support program for and through our distributor network.

The Premier VS-VH Vacuum System is the culmination of decades of infrared expertise and commitment to quality products. The VS-VH System is easy to install and maintain, offers flexibility of design which is unmatched in the industry and provides economical and trouble-free operation.

Important

These instructions, the layout drawing, local codes and ordinances, and applicable standards such as apply to gas piping and electrical wiring comprise the basic information needed to complete the installation and must be thoroughly understood along with general building codes before proceeding.

Only personnel who have been trained and understand all applicable codes should undertake the installation. SRP Representatives are Factory Certified in the service and application of this equipment and can be called on for helpful suggestions about installation.

Operating Principle

The PREMIER VS-VH System operates on the following basic principles:

- ONE Vacuum Setting is required for all Branches in the System and is independent of which Burner Model is installed.
- Individual Air Plates have been specially engineered to co-ordinate with the 'Position' a Burner is placed in on any Branch of the System.
- Individual Burner Models are specific for a desired BTU/hr heat rating.
- Systems may be operated in the following mode:
 - Single Rate: Entire system operates at ONE fixed Rate by setting the Vacuum Setting using Manual Dampers.
 - Modulating Rate: Burner output Rates may be decreased from ideal designed rate by up to 40%.
 - The use of Variable Frequency Drive which adjust the Vacuum Settings of all heaters in the system by adjusting the pump motor speed allowing the System to modulate.
 - The use of Motorized Dampers which adjust the Vacuum Settings of individual Branches allows the System to modulate the overall Heat Output during operation to meet the building demand.

APPLICABLE CODES

Installations must comply with local building codes, or in their absence, the latest edition of the national regulations and procedures listed below:

General Installation and Gas Codes

Heaters must be installed only for use with the type of gas appearing on the rating plate, and the installation must conform to the National Fuel Gas Code, ANSI Z223.1 (NFPA 54) in the USA and the Natural Gas and Propane Installation Code, CSA B149.1 and B149.2 in Canada.

This heater is approved for indoor installation only. Not for use in residential dwellings, refer to rating plate

Aircraft Hangar Installation

Installation in aircraft hangars must conform to the Standard for Aircraft Hangars, ANSI/NFPA 409 in the USA and CSA B149.1 and B149.2 in Canada.

Public Garage Installation

Installation in public garages must conform to the Standard for Parking Structures, NFPA-88A or Standard for Repair Garages, NFPA 88B, in the USA and CSA B149.1 and B149.2 in Canada.

Parking Structures

Technical requirements are outlined in the Standard for Parking Structures, ANSI/NFPA 88a in the USA and CSA B149.1 and B149.2 in Canada.

Gas Supply Lines

Gas supply pipe sizing must be in accordance with the National Fuel Gas Code, ANSI Z223.1 (NFPA 54) in the USA and the Natural Gas and Propane Installation Code, CSA B149.1 and B149.2 in Canada.

A 1/8" inch NPT plugged tap must be installed in the gas line connection immediately upstream of the burner farthest from the gas supply meter to allow checking of system gas pressure.

Electrical

All heaters must be electrically grounded in accordance with the National Electric Code, ANSI/NFPA 70 in the USA, and the Canadian Electric Code, CSA C22.1 in Canada, and must comply with all local requirements.

Venting

Refer to the National Fuel Gas Code, ANSI Z223.1 (NFPA 54) in the USA and the Natural Gas and Propane Installation Code, CSA B149.1 and B149.2 in Canada for proper location, sizing and installation of vents as well as information on termination clearance requirements when penetrating combustible walls for venting purposes.

EQUIPMENT SPECIFICATIONS

System Layout Types




Figure 1: Symmetric System Overview




Figure 2: Non-Symmetric System Overview

Basic Components




Figure 3: Common Component Dimensions




Figure 4: Specialty Component Dimensions

*A List of Parts and Part Numbers can be found in the PARTS Section at the end of this Manual.

Burners

General Burner Specifications

Gas Supply

Natural Gas:	Minimum	5.0" W.C.
	Maximum	14.0" W.C.

Manifold Pressure: Natural Gas: 0" W.C.

Inlet Connection: ½" NPT male

Electric Supply

120 VAC, 60 Hz, 0.2 Amp: 36" (0.9 m) cord connector with grounded 3-prong plug.

Flue and Outside Air Connection

4" type C duct for flue adaptor and outside air (optional) provided at the heater.




Figure 5: Burner Dimensions




Figure 6: Locations of Burner Labels/Stickers

Premier VS-VH - Chart of Burner Rates

Important: This burner is a variable input appliance.
See chart below to determine appliance burn rate.

A flow plate appropriate to the position of the burner in the system **MUST** be installed (see Manufacturer's).

Positions are identified in ascending order from the start end of the system.

Note: An end vent vacuum intermediate to those shown will result in rates intermediate and proportional to those indicated.

Table A: Burner Rates

Radiant Branch End Vent Vacuum [Inches W.C.]	Premier VS-VH02	Premier VS-VH04	Premier VS-VH06	Premier VS-VH08	Premier VS-VH10	Premier VS-VH12
3.4						120,000
3.0	20,000	40,000	60,000	80,000	100,000	110,000
1.7	12,000	24,000	36,000	48,000	60,000	66,000
Gas Orifice Size	#43	#31	#27	#13	#1	#K

As-Built Burner Position Label

BURNER No.

As-Built - if Burner will not be placed in this Position the
Air Plates will need to be changed prior to installation,
consult manual for further details.

Vacuum Pump A

Electric Supply: 115/230 VAC, 60Hz, 1 PH, 0.75 HP

Tube Connection: 6" dia. Inlet and 4" dia. Outlet




Figure 7: Vacuum Pump A - Available in RH or LH Style

Vacuum Pump B

Electric Supply: 208/230/460 VAC, 60Hz, 3 PH, 1.5 HP

Tube Connection: 6" dia. Inlet and 6" dia. Outlet




Figure 8: Vacuum Pump B - Available in RH or LH Style

CLEARANCE TO COMBUSTIBLES

A general clearance of 18" (0.5 m) in every direction is recommended for servicing only around each Burner, Vacuum Pump, and End Vent Cap air supply (at the far end of each Radiant Branch) also to ensure adequate air flow in and around the Heating System.

In addition to this it is very important to observe the minimum clearance to combustibles at all times to avoid any possibility of property damage or personal injury.

WARNING

- Clearances as marked on the heater body must be maintained from vehicles parked beneath. Signs should be posted identifying any possible violation of the clearance distances from the heater in all vehicle areas.
- Maximum allowable stacking height in storage areas should be identified with signs or appropriate markings adjacent to the thermostat or in a conspicuous location.

Table B lists the minimum clearance to combustible materials for various installation configurations. Note that standard clearances also apply to installation above T-bar ceilings and above decorative grills. Additional clearance may be required for glass, painted surfaces and other materials which may be damaged by radiant or convective heat.

Combustible materials are considered to be wood, compressed paper, plant fibres, plastics, Plexiglas or other materials capable of being ignited and burned. Such materials shall be considered combustible even though flame-proofed, fire-retardant treated or plastered.

Elbows and U-bends are un-heat treated aluminized material and are typically installed without reflectors. Reflector miter kits are available for U-bends and elbows.

Adequate clearance to sprinkler heads must be maintained

The stated clearance to combustibles represents a surface temperature of 90°F (50 °C) above room temperature. Building materials with low heat tolerance (**such as plastics, vinyl siding, canvas, tri-ply, etc....**) maybe subject to degradation at lower temperatures. **It is the installer's responsibility to assure that adjacent materials are protected from degradation.**





Note 1:

Bottom Shields are approved for all burner sizes. The "below" clearance (dimension C in Table A) may be reduced by 25% when an approved Bottom Shield is used.

Note 2:

Reduced clearances downstream from the burner are approved for all configurations. Dimensions "B", "C", and "D" in Table A can be reduced for locations 25 ft (7.6 m) or more downstream from a burner, before the next burner, by 50%

Table B: Required Clearance to Combustibles

Dimensions: Inches (cm)		Burner Rate in Thousands of BTU/hr [MBH]					
Reflector Configurations	Dim	20	40	60	80	100	120
 Horizontal	A	2 (5.1)	2 (5.1)	2 (5.1)	2 (5.1)	2 (5.1)	4 (10.2)
	B	15 (38.1)	15 (38.1)	17 (43.2)	23 (58.4)	28 (71.1)	30 (76.2)
	C	45 (114.3)	45 (114.3)	50 (127)	53 (134.6)	58 (147.3)	60 (152.4)
	D	15 (38.1)	15 (38.1)	17 (43.2)	23 (58.4)	28 (71.1)	30 (76.2)
 45° Reflector Tilt	A	4 (10.2)	4 (10.2)	4 (10.2)	4 (10.2)	4 (10.2)	4 (10.2)
	B	4 (10.2)	4 (10.2)	4 (10.2)	4 (10.2)	4 (10.2)	4 (10.2)
	C	40 (101.6)	40 (101.6)	48 (121.9)	52 (132.1)	60 (152.4)	66 (167.6)
	D	38 (96.5)	38 (96.5)	42 (106.7)	46 (116.8)	50 (127)	59 (149.9)
 One Side Reflector	A	2 (5.1)	2 (5.1)	2 (5.1)	2 (5.1)	2 (5.1)	4 (10.2)
	B	4 (10.2)	4 (10.2)	4 (10.2)	4 (10.2)	4 (10.2)	4 (10.2)
	C	50 (127)	50 (127)	56 (142.2)	65 (165.1)	70 (177.8)	73 (185.4)
	D	32 (81.3)	32 (81.3)	34 (86.4)	38 (96.5)	43 (109.2)	49 (124.5)
 Two Side Reflectors	A	2 (5.1)	2 (5.1)	2 (5.1)	2 (5.1)	4 (10.2)	4 (10.2)
	B	9 (22.9)	9 (22.9)	14 (35.6)	16 (40.6)	18 (45.7)	21 (53.3)
	C	50 (127)	50 (127)	56 (142.2)	64 (162.6)	71 (180.3)	74 (188)
	D	9 (22.9)	9 (22.9)	14 (35.6)	16 (40.6)	18 (45.7)	21 (53.3)

*Clearance to combustibles for non-reflected fittings is 18" (0.5 m).

INSTALLATION

Preparation

Most vacuum system designs are laid out on a clean blank sheet of paper. Unfortunately, typical construction does not permit this unimpeded access and therefore some planning and preparation early in the project will save much time and effort later.

Start by reviewing the installation procedure. Examine where the equipment will be installed and how it will be supported. Please pay special attention to any objects that might be in the way or in close proximity to the heating system. Refer to Table B (Clearance to Combustibles) to ensure a safe distance between the heating system and any combustible materials.

Acquaint yourself with the standard components referred to in this manual. Many of these components are shown in detail in Figure 3. They are also shown in general assembly form in Figure 1 and Figure 2 to illustrate where the components fit in a typical symmetrical system and a non-symmetrical system. (These Figures are found in the Equipment Specifications section.)

If possible, lay the entire system out on the floor prior to installation. This will help identify any potential problems with the installation as well as any discrepancy in component quantity. Ensure that all Burners are those specified for the planned system in both output and gas type.

***DO NOT TRIM/CUT ANY Combustion Tube, adjust the System to fit around the Combustion Tubes.**

Layout Limits

Ensure that the System Layout meets the limits required in Table C and Table D.

Table C: Radiant Tube System Layout Limits

Burner Model No.	Burner Rating [BTU/hr]	Radiant Tube Lengths (Distance between Burners) [ft (m)]			Minimum Distance to Elbow [ft (m)]	
		Minimum	Recommended	Maximum	Before Burner	After Burner
Premier VS-VH02	20 000	10 (3.1)	15 (4.6)	20 (6.1)	3 (0.9)	5 (1.5)
Premier VS-VH04	40 000	15 (4.6)	20 (6.1)	25 (7.7)	3 (0.9)	10 (3)
Premier VS-VH06	60 000	20 (6.1)	25 (7.7)	35 (10.7)	3 (0.9)	15 (4.6)
Premier VS-VH08	80 000	20 (6.1)	30 (9.2)	45 (13.7)	3 (0.9)	15 (4.6)
Premier VS-VH10	100 000	30 (9.2)	40 (12.2)	60 (18.3)	3 (0.9)	15 (4.6)
Premier VS-VH12	120 000	40 (12.2)	50 (15.3)	70 (21.4)	3 (0.9)	20 (6.1)

*When minimum Radiant Tube lengths are used, minimum tailpipe length must be increased by 50%

Table D: Tailpipe Lengths Required for Various Branch Layouts

Burner Model No	Total Number Burners in Branch	Total Output for Branch [MBH]	Minimum Tailpipe for Branch [ft (m)]
Premier VS-VH02	1	20	10 (3.0)
	2	40	10 (3.0)
	3	60	20 (6.1)
	4	80	20 (6.1)
Premier VS-VH04	1	40	20 (6.1)
	2	80	20 (6.1)
	3	120	30 (9.1)
	4	160	30 (9.1)
Premier VS-VH06	1	60	30 (9.1)
	2	120	30 (9.1)
	3	180	40 (12.2)
	4	240	40 (12.2)
Premier VS-VH08	1	80	40 (12.2)
	2	160	40 (12.2)
	3	240	40 (12.2)
	4	320	60 (18.3)
Premier VS-VH10	1	100	40 (12.2)
	2	200	50 (15.2)
	3	300	60 (18.3)
	4	400	60 (18.3)
Premier VS-VH12	1	110 / 120	40 (12.2)
	2	220 / 240	50 (15.2)
	3	330 / 360	60 (18.3)
Exceptions: 1) When minimum Radiant Tube lengths are used, minimum tailpipe length must be increased by 50% 2) If using Common Tailpipe refer to the following to determine the Minimum Common Tailpipe length required: 1 - Add up usual recommended lengths of Tailpipe (from data in this Table) 2 - Subtract the length of any Tailpipe which will NOT be Common 3 - If result is > 40' remaining, multiply by 0.6 for Minimum Common Tailpipe Length OR 3 - If result is ≤ 40' remaining, multiply by 0.75 for Minimum Common Tailpipe Length 3) When using 5" Ø Tailpipe, the Required Tailpipe Lengths may be reduced by 25%			

Assembly Overview Notes

Generally, there is no unique sequence for installation of the Premier VS-VH system. A review of the job site will often indicate a logical installation order. However, it is typical to start at the end of the branch with the furthest Burner location and continue that Branch downstream towards the Vacuum Pump, then begin again with the next Branch. Generally, 10 ft. (3 m) increments of Tube and Reflector can be used until one reaches the Common Tailpipe areas or Vacuum Pump connections. The general order of material in this manual is recommended for low-hassle installation purposes.

The Installation of the Entire System potentially consists of 5 individual Parts, one Part for each major component/system:

1. Radiant Line System, (Heat Exchangers)
2. Vacuum Pumps and Ventilation Systems,
3. Optional Combustion Air Supply System,
4. Gas Supply System, and
5. Electrical System(s)

Directions for the installation of each component/system are therefore found in the respective sections along with general information and safety notes as required.

1. Radiant Line System

For the purpose of this section the term “Radiant Line System” will refer only to the main heat exchanging components: Tubes, Burners, Reflectors, Tailpipes and attached Optional pieces. These must be hung from ceiling supports and form the main Radiant Lines and Branches of the Heat Exchanger System.

Installation of the Radiant Line System has been divided into 6 main parts as follows:

- Radiant Line Tubes
- Tailpipe Tubes
- Burners
- Reflectors
- Optional Shield Equipment
- Optional Deco-Grille

The order they are listed in is recommended for ease of installation and allows for adjustments to be made easily if required. Other orders of installation are possible; please note that there are certain components which, once installed, will make it more difficult to install others. Thoroughly read through the following installation directions for details on individual components.

Figure 9 illustrates the relationship of many of the various components of the Radiant Line System and will be a useful reference at many times during the installation.

NOTE: Close all open ended “S” hooks and turnbuckles to avoid unhooking chain with inadvertent contact.

NOTE: The Premier VS-VH System does not typically require the use of Baffles, if Baffles are desired please consult with the Manufacturer (SRP) prior to installation.

A - Radiant Line Tubes

All Combustion Tubes are heat-treated aluminized steel tubes. The remaining Radiant Tube length can be either hot rolled or heat-treated aluminized depending on the system design.

1. Locate hanging chain at predetermined points in the structure using methods as shown in Figure 10. The first 2 hanging points are approximately 7.5 ft. (2.3 m) apart to fully support each end of the first Tube. Thereafter spacing of 10 ft. (3 m) is acceptable, i.e. one hanging point per Tube. Ensure that Reflector Hangers located on a Combustion Tube will be within 8" (20 cm) of the Burner. Ensure that the mounting height allows a downward slope of $\frac{1}{4}$ " per 10 ft. (7 mm per 3 m) towards the Vacuum Pump location.
2. Welded link chain with a working load limit of at least 500 lbs. (230 kg) is recommended. The suspension mechanism must allow for lateral expansion of the Tubing. A minimum length of 12" (30 cm) of hanging chain is recommended. Using turnbuckles between the chain and the Reflector Hanger allows for easy height adjustment later.




Figure 9: Radiant Line System - Component Relationships




Figure 10: Ceiling Mounting/Hanging Options

3. Install an End Vent Cap at the beginning of each Branch (open end of the first Combustion Tube) and fasten it with a #8 x 3/8" screw as shown in Figure 11 below.




Figure 11: End Vent Cap Orientation

4. Fasten the Reflector Hanger to the end of the hanging chain and place the Tube in the hanger. Ensure that Combustion Tubes have the Burner mounting hole positioned at 12 o'clock and facing downstream. (Refer to Figure 12).




Figure 12: Tube and Reflector Hanger Detail

5. Join consecutive pieces of Tube using Couplings. Insert one end of both Tubes fully into the Coupling. (Refer to Figure 13). These should be tightened as the Tubing is put in place, as it is more difficult to do so once the Reflector is installed. Tighten band clamps alternately to prevent buckling of the sleeve, set to Torque listed. Ensure that the weld seams on ALL Tubes are facing down.




Figure 13: Tube Coupling Installation




Figure 14: View of System after Installation of Radiant Line Tubes

Note: System is now ready for Tailpipe installation(s).

Note: System is now ready for Burner installation(s).

B - Tailpipe Tubes

1. Continue to install Hangers*, Tubes and Couplings as per Installation Part 1-A: Steps 1 to 4. Ensure that the mounting height allows a downward slope of $\frac{1}{4}$ " per 10 ft. (7 mm per 3 m) towards the Vacuum Pump location.
*On Tubes which will NOT have Reflectors, i.e. Tailpipe, the use of Hanger Straps instead of Reflector Hangers is approved.
2. BEFORE installing the Tee Section between the Branch Tailpipes and the Common Tailpipe determine where the Damper Couplings need to be installed.
3. Check which type of System is being installed, Symmetric (S) or Non-Symmetric (N) as per Figure 1 and Figure 2. Dampers are positioned to allow the Vacuum Setting at the Branch End Vent to be adjusted individually for each Branch. Symmetric/Identical Branches require the same Vacuum setting, so One Damper coupling is located before the Tailpipe splits into separate Branches. Non-Symmetric Branches require a separate Damper Coupling for each Branch. For Modulating Rate Systems ensure that Motorized Damper Couplings are used.

Damper Couplings are ONLY installed in the locations on the System where the respective letter reference "S", OR "N" is located in Figure 15, on all other connections use normal Couplings. Dampers and Couplings are installed using the same method. (See previous section.)




Figure 15: Typical Tailpipe Connections

- Continue to install the Common Tailpipe in the same manner as all other Tubing. Ensure that the mounting height allows a downward slope of $\frac{1}{4}$ " per 10 ft. (7 mm per 3 m) towards the Vacuum Pump location.

Note: System is now ready for Vacuum Pump and Ventilation connection(s).

C – Burners

Each Burner in a Premier VS-VH Branch must be placed in its appropriate position, and have the appropriate Air Plate installed.

Burner Position No.1 is at the furthest end of the branch from the Vacuum Pump and the Burner number increases as the branch runs towards the Vacuum Pump.


(As shown in Figure 16 and referred to in your System Design Layout)

Each Burner is shipped with a Burner Rating Plate and As-Built Burner Position Label affixed, with the corresponding Air Plate installed. If the System Design Layout changes and the Burner must be placed in a position other than the As-Built Burner Position, then the Air Plate will need to be replaced with the appropriate one for the required new Position.

(See below figure for details.)

- Confirm Burner Positions and change-out Air Plate(s) as necessary.

Each burner position in series along a branch requires the burner in that location to have a specific Air Plate installed. Burners will come with the Air Plate for a specific Position installed. The Position will be identified by the As-Built Burner Position Label (Burner No. #) If, due to changes in the System Design Layout, any Burner is NOT going to be placed in the labeled As- Built Position, prior to installation the Air Plate will need to be removed and replaced, as shown in Figure 17, with the corresponding Air Plate as given in Table E for the Burner Model and the Position that it will be placed in. Contact the Supplier to obtain the correct Air Plates.



Example System 2





Figure 16: Burner Position Reference Diagram

Table E: Burner Set-up – Install the Required Air Plate in the Correct Burner

Burner Model No.	Branch Set Up			
	Burner Air Plate (Part No.) Required for Each Position			
	Position 1	Position 2	Position 3	Position 4
Premier VS-VH02	VS084	VS085	VS086	VS087
Premier VS-VH04	VS088	VS089	VS090	VS091
Premier VS-VH06	VS092	VS093	VS094	VS095
Premier VS-VH08	VS096	VS097	VS098	VS099
Premier VS-VH10	VS100	VS101	VS102	VS103
Premier VS-VH12	VS104	VS105	VS106	




Figure 17: Air Plate Change-Out Procedure

2. Use the J-bolt (included with the Burner packaging) to clamp the Tube snugly at the first Reflector Hanger after a Burner mounting hole location. This prevents the Tube from twisting once the Burner is installed. (Refer to Figure 9 and Figure 18)
3. J-bolts must be installed before the Reflectors are inserted.




Figure 18: J-Bolt Installation Detail

4. Install each Burner. Ensure the gasket is properly in place, a small amount of contact cement will hold the gasket. Position the Burner completely to the back of the installation slot as shown in Figure 19. Ensure that little or no Tube is in view through the Viewing Glass/Window.
5. Fasten the U-bolts but do NOT over tighten as it will damage the Combustion Tube.




Figure 19: Burner Installation

Note: Burners are now ready for Fresh Air Supply connection(s) as necessary.

Note: Burners are now ready for Electrical System connection(s).

Note: Burners are now ready for Gas Supply System connection(s).




Figure 20: View of System after Installation of Burners

D - Reflectors

1. Install Reflectors **after** any Tube Couplings and J-bolts they cover have been installed. (For ease of installation it is suggested to install Burners **before** the Reflectors; however, it is possible to do the reverse.)
2. *If the System Plan includes **Bottom Shields** these **MUST be put on before the Reflectors** as there will be limited access afterwards. For details see Section E - Optional Shield Equipment.
3. Begin the first Reflector after a Burner with an End Cap about 3" (7.6 cm) downstream of the Burner as shown in Figure 21 and Figure 22. Install the End Cap using #8 x 3/8" screws. Leaving space in the Reflector run allows unimpeded installation and servicing of the Burner.
4. Install Reflector Brackets. Place one at each Reflector overlap position and one in the middle of each 10 ft. (3 m) Reflector length. Secure the Brackets loosely with #8 x 3/8" screws. **Tighten only** the screws for Brackets in the centre of alternating Reflectors and at every second overlap location. The remaining Reflector Bracket screws are left loose to accommodate system movement/expansion. Refer to Figure 24 and to Figure 9 for a visual of which bolts to tighten and which to leave loose.
5. Continue to slide the Reflectors into place within the Tube/Reflector Hanger up to the next Burner position. Overlap the Reflectors as shown in Figure 9 and Figure 24.

Note: Reflectors should overlap adjacent reflectors 4" to 6". Be sure not to tile reflector sections; that is, reflector sections must be either above both adjacent reflector sections or below both adjacent reflector sections.




Figure 21: Reflector End Cap and Bracket Detail




Figure 22: View of System after Installation of first Reflector

6. When approaching successive Burner locations, ensure the Reflector is as far under the Burner (close to the Burner mounting hole) as possible, as shown in Figure 22. *Install an End Cap using #8 x 3/8" screws on the open end of the Reflector which will be under the Burner at the end of the Reflector run.
*Burner Reflectors are for use instead of End Caps. If Burner Reflectors, for Continuous Reflector runs, are required by the System Plan please refer to Section E - Optional Shield Equipment for alternate Reflector installation details.
7. Stop the Reflector run as per plan or when reaching an Elbow or Tee and install an End Cap at the end of the Reflector run using #8 x 3/8" screws.
*When using the optional Corner/Mitered Reflectors refer to Figure 26 in Section E - Optional Shield Equipment, for details on how to assemble Reflectors sections instead of installing End Caps.




Figure 23: Standard Reflector and Burner Relative Positioning




Figure 24: View of System after Installation all Reflectors

E - Optional Shield Equipment

Bottom Shields

Bottom Shields do not need to overlap. Each 5 ft. (1.5 m) section is held with two Support Brackets. Secure each of the Support Brackets around the Tube with supplied fastener and attach to bottom shield with #8 x 3/8" screws. Refer to Figure 25 below for reference.




Figure 25: Bottom Shield Installation Detail

Burner Reflectors

Burner Reflectors are used to maintain a continuous Reflector surface along the length of the Heat Exchanger instead of ending and restarting Reflector runs with End Caps at each Burner location.

Burner Reflectors are installed after the Burner installation, and before/during assembly of the main Reflector run. All pieces are connected using #8 x 3/8" Screws. The Side pieces and End Sections are installed first to create a Base to secure the Burner Reflector sections to. Overlap the Burner Reflectors with Standard Reflectors and secure the Reflectors together with Support Brackets. Refer to the sequence of images in Figure 26 for more detail.




Figure 26: Burner Reflector Installation Sequence Details

Corner/Mitered Reflector

Corner/Mitered Reflector Kits are used above elbow locations instead of stopping and restarting a Reflector run to accommodate the elbow. Secure the Mitered Reflectors together using the Two (2) Corner Brackets as shown in Figure 27. Also insert #8 x 3/8" screws at each 'tab' location along the top of the Reflectors.




Figure 27: Optional - Corner (Mitered) Reflectors

Side Reflectors

Side Reflectors are 124" (3.15 m) long. Fasten one Side Reflector per main Reflector tightly with #8 x 3/8" screws spaced about 18" (0.5 m) apart. Install three (3) Side Reflector Brackets per Side Reflector, spaced about 48" (1.2 m) apart, using #8 x 3/8" screws. DO NOT install brackets where Reflectors overlap. Refer to Figure 28 for details.




Figure 28: Side Reflector Installation Detail

F - Deco-Grille Option

Premier VS-VH System heaters are approved for the addition of a Decorative Grille [Deco-Grille] either directly to the Reflector or as part of a T-bar installation where the Heater System is above the ceiling structure. Refer to Figure 29 and Figure 30 for their respective details.




Figure 29: Deco-Grille – Mounted Directly to Heater




Figure 30: Deco-Grille – Mounted With T-Bar

2. Vacuum Pump and Venting

Vacuum Pump

General Requirements

The Vacuum Pump (with permanently mounted motor affixed) is generally located at the height of the system, bolted to a platform or support structure that is either suspended from the ceiling members or is bolted to a column or building sidewall. The Vacuum Pump scroll is orientated for the preferred horizontal discharge, but can be rotated 90 degrees in the field for vertical discharge.

(Refer to Figure 31, Figure 32 and Figure 33 for visuals of Vacuum Pump mounting options.)

*If a lengthy heater run has a 90 degree elbow with a short run to the Vacuum Pump, consider placing the Pump somewhat off (past) the centerline of the connecting Tailpipe so that as the system grows the Flexible Boot Connection in fact improves performance.

Safety Warnings

Confirm that the Vacuum Pump's impeller rotates in the same direction indicated by the arrow on the pump scroll. To reverse rotation, see instructions on the motor.

WARNING - DO NOT OPERATE THE VACUUM PUMP WHEN NOT INSTALLED

- Unguarded openings can entangle clothing and severe injury can result
- Unrestricted air flow into Vacuum Pump can cause the motor to overload

To ensure maximum safety, a vacuum proving switch is mounted near the inlet of the vacuum pump and electrically interlocked to the burner power circuit. No fuel gas can flow, or ignition begin before the vacuum proving switch has established the presence of a blower induced vacuum.

See the "Electrical Connections" section for details on wiring the switch.

Vacuum Pump Mounting

1. Install Vacuum Pump as per designed system mounting location and position.
2. Ensure that mounting supports are sufficient to withstand the weight and vibration of the Vacuum Pump and Ventilation System. Welded link chain with a working load limit of at least 200 lbs. (91 kg) is recommended for mounting vacuum pumps only.
3. Install using the Vacuum Pump Mounting Kit if purchased. (Chain and threaded rods for ceiling mounting are NOT included in package.)
4. Ensure elevation of Inlet will allow for the alignment of the Tubing with a downward slope of $\frac{1}{4}$ " per 10 ft. (7 mm per 3 m) towards the Vacuum Pump.
5. Ensure that the isolators are placed between the Pump housing and the mounting supports to reduce vibration transfer to the structure.

See Figure 31, Figure 32 or Figure 33 respectively for mounting type details.




Figure 31: Column Mounting – Recommended Pump Suspension




Figure 32: Side Wall Mounting - Recommended Pump Suspension




Figure 33: Ceiling Mount - Recommended Pump Suspension

Venting

The Premier VS-VH System is approved for both Sidewall (Horizontal) and Roof (Vertical) Venting.
(Refer to Figure 34 and Figure 35)

This system is considered a Category III venting system.

- The heater operates at a positive vent pressure.
- Use an approved to S636 or UL1738 Category III venting system, or a single wall vent pipe with all joints and seams sealed with heat-resistant pliable sealant, such as high temperature RTV silicone for temperatures up to 650°F [343°C]. Prior to placing the heater in operation conduct a leak test with heater running using a soap solution.

General Requirements

Venting must comply with the National Fuel Gas Code, ANSI Z223.1/NFPA-54 in the USA and CSA B149.1/B149.2 Installation Code in Canada.

Note: ANSI Z223.1 specifies a minimum 4 ft. (1.22 m) horizontal vent terminal clearance from gas and electric meters, regulators and relief equipment (see clause 1/31/3-m4).

Items Common to both Codes:

(Always check for changes to Code – list is for example only)

- Horizontal discharge must be not less than a specified distance above grade
- Vent must not terminate within a specified distance below, horizontally from, or above any window, door or gravity opening to a building.
- Discharge must be at least a specified distance from any opening through which vent gases can enter a building.
- Venting must terminate beyond any combustible overhead and at a height sufficient to prevent blockage by snow.
- Venting through a combustible wall requires an approved thimble.
- Vent should extend beyond wall surfaces to avoid splash-back condensation.
- Corrosion resistant materials should be employed for venting.

General Installation Notes

- Never connect venting to a chimney flue serving a separate solid-fuel burning appliance.
- Rigid, spiral wrap, corrosion resistant ducting is recommended to facilitate leak-proofing the system. Venting runs over 25 ft. (7.6 m) in length may need to be insulated.
- Always install venting with a down-slope of at least ¼" per 10 ft. (7 mm per 3 m) towards the Vacuum Pump location.
- Ensure that ducting is well suspended to avoid low spots where condensate can gather.

System Requirements

Horizontal Venting:

Material: Minimum 24 gauge, GALV, single wall Pipe
Size: 4 " or 6 " dia. as per Vacuum Pump Outlet
Sealant: RTV Silicone
Fasteners: Minimum of Two (2) sheet metal screws #8 x 3/4" per joint.

Table F: Size Conditions for Exhaust Venting

Vent Length [ft (m)]		Vacuum Pump A		Vacuum Pump B	
Maximum	Minimum	Vent Dia.	# Elbows	Vent Dia.	# Elbows
10 (3.0)	2 (0.6)	4 Inch	Up to 2	6 Inch	Up to 3
50 (7.7)	2 (0.6)	5 Inch	Up to 2		

For specific Part Numbers of Wall Vent connection pieces see Figure 34 or the listing in the PARTS section of this manual.

Vertical Venting:

- When venting through a roof, use single-wall vent pipe in the building and an approved clearance roof thimble. A B type vent for the portion of the vent system passing through the roof may be used. Use B type vent materials for stacks above the roof line. If using vent lengths greater than 15' (5m), condensation will form in the vent pipe. Insulation and additional sealing measures (high temperature silicone at all seams) may be required.

Ventilation Connections

Install Ventilation system pipes, etc. as per design/conformance with required Codes and connect with Vacuum Pump Outlet. Ensure that there is a minimum of 2" (5 cm) between the Vacuum Pump outlet and the first rigid section of the Ventilation piping to avoid mechanical contact between the two. Use the Silicone Connector Boot to connect the Vent Pipe to the Vacuum Pump Outlet.

(Refer to Figure 34 or Figure 35 respectively for mounting type details.)




Figure 34: Side Wall Mounting - Recommended Venting (Horizontal)




Figure 35: Ceiling Mounting - Recommended Venting (Vertical)

Additional Pump Connections and Equipment

1. Connect the Reducer to the end of the Common Tailpipe using a 4" Butt Joint Clamp. Ensure a minimum of 2" (5 cm) clearance between the Reducer and the Pump Inlet.
2. Install the Flexible Boot Connector between the Reducer and Pump Inlet, to reduce vibration and noise transmission, using a gear clamp at either end, as shown in Figure 36.




Figure 36: Tailpipe to Vacuum Pump Connections

3. Seal all joints and seams using high temperature Silicone Sealant (RTV Silicone).

4. Where condensing designs are specified, a Condensate Drain may be installed as shown in Figure 37. Ensure connection to Drain Pipe is flexible to allow for system movement / expansion during operation, and that an appropriate Neutralization Device is installed as required.




Figure 37: Condensate Drain Detail – Optional

3. Optional Combustion Air Supply

An air supply at atmospheric pressure of 40 CFM per 100,000 BTU/hr. to each Burner and the end of each Radiant Branch (at the End Vent Cap) is usually sufficient.

Under certain circumstances of very dirty or wet environments, or extremely negative building pressure, a Combustion Air Supply System that is connected to the fresh air outside the building may be recommended. The Combustion Air Supply System must be designed with accepted HVAC design methods to ensure adequate supply of air to each Burner and Radiant Branch. This Combustion Air can be supplied using a Blower. Supply at the Burner must be at atmospheric pressure therefore it may be necessary for the Installer to insert Damper Couplings to allow adjustment of pressure just before the connection to each Burner and at the end of each Branch. **The Blower must be electrically interlocked with the Vacuum Pump, details can be found in “Electrical Connections”.**

Combustion Air Supply Duct Connections

1. Install Blower if required.
2. Install Combustion Air Supply ductwork and Damper Couplings as required.
3. Each Burner can be fitted with a 4" dia. fitting to accept 4" dia. Type C-Duct or 4" PVC pipe. Provision for thermal expansion of the System must be made when considering Combustion Air Supply Ducting. Ensure that the System movement/expansion does not restrict the supply of fresh air to the Burners or the Radiant Branches. (Refer to Figure 38 for clearance requirements)

As required, connect the Supply Ductwork in the same manner as for the Burner. (Refer to Figure 38 for details), DO NOT remove the End Vent Cap from the Radiant Branch to make this connection.




Figure 38: Outside Combustion Air Detail

4. Gas Supply System

General Requirements

Supply Lines

The Gas Supply Meter and the Supply Service must be sufficiently large to supply gas to the total building gas load including the heating equipment. Additionally, the gas distribution piping must be designed according to local and national ordinances. Generally, systems designed with a maximum $\frac{1}{2}$ " W.C. total pressure drop (low pressure) meet this requirement.

Gas supply pipe sizing must be in accordance with the National Fuel Gas Code, ANSI Z223.1 (NFPA 54) in the USA and CSA B149.1 and B149.2 Installation Codes in Canada.

A $\frac{1}{8}$ " NPT plugged tap must be installed in the Gas Line connection immediately upstream of the Burner farthest from the Gas Supply Meter to allow checking of system gas pressure.

A Gas Shut-off Valve must be installed parallel to EACH Burner Gas Inlet connection.

Before connecting Burners to the Gas Supply System, verify that high pressure testing of the Gas System has been completed. Burners must be isolated from any pressure testing in excess of $\frac{1}{2}$ psi (3.5 kPa).

Failure to comply may expose the Burner components to damage due to high pressure, requiring replacement of key components.

Flexible Gas Connector Lines

- Gas Flex Line Connector sizes for Burners with firing rates: (1 MBH = 1 000 BTU/hr)
 - Requires 1/2" dia. x 36" (90 cm) long

In Canada: Only use Type I Hose Connector that is (a) certified as being in compliance with the Standard for Elastomeric Composite Hose and Hose Couplings for Conducting Propane and Natural Gas, CAN/CGA 8.1; and (b) of a length of 36" ± 6" (90 ± 15 cm).

In the United States: The Flexible Metallic Connector Hose must be certified for use on a Radiant Tube type Infrared Heater per the Standard for Connectors for Gas Appliances, ANSI Z21.24/CSA 6.10.

Failure to install the Gas Connection in the approved manner will result in a hazardous and potentially deadly situation due to the movement of the heat exchanger and burner in the normal course of operation.

Installation or repair of this heater should only be done by personnel qualified for the installation of powered gas appliances.

(Certified by the local or national regulating body)

Flexible Gas Connector Line

A Flexible Gas Connector of approved type and size must be installed as shown in Figure 39 and Figure 40, in one plane, and without sharp bends, kinks or twists. A smooth loop of approximately 12" (30 cm) in diameter is best. Refer to Figure 39 for examples of correct and incorrect positioning





Figure 39: Installation Position Instructions



WARNING: CONNECTOR MUST BE INSTALLED IN "D" CONFIGURATION. USE ONLY THE 36" (90 cm) LONG CONNECTION OF ½" OR ¾" (12.7 OR 19 mm) NOMINAL ID THAT WAS FURNISHED WITH THIS HEATER.

Figure 40: Connector Installation Details

5. Electrical Connections

General Requirements

If electronic components are to be installed in an area that is subject to water (drips, spray, rain etc.) then sufficient means shall be provided by the Installer to protect the components from water ingress.

Ensure that all Electricity to the Supply locations involved has been 'disconnected' and 'locked out' as per local and national safety requirements before proceeding with any part of the Electrical installation.

General Wiring

All field wiring and connections must be in accordance with the National Electric Code, ANSI/NFPA 70 in the USA, and the Canadian Electric Code, CSA C22.1 in Canada, and must comply with all local requirements.

All heaters must be connected and electrically grounded in accordance with the National Electric Code, ANSI/NFPA 70 in the USA, and the Canadian Electric Code, CSA C22.1 in Canada, and must comply with all local requirements.

Thermostats

Preference is to have each Branch as a separate Heating Zone with a separate Thermostat for better control of heat levels and fuel usage.

Thermostats must be located/mounted within the operating heat envelope of the Radiant Line Branch being controlled. Thermostats must be protected/shielded from direct 'line of sight' with the Radiant Tubing and Reflectors.

Control Methods and Devices

1. Single Thermostat: Entire system operates as one Heating Zone, ON or OFF using one Relay to control the Vacuum Pump, Vacuum Switch and Burner Power (Figure 41).
2. Multiple Thermostats: System Branches operate as multiple individual Heating Zones which can be separately controlled ON or OFF. Burners are controlled ON/OFF by the Thermostat they are wired/connected to using one of the following control devices:
 - a. **Relays (Two)** - 2 Thermostats - Hardwired control of Vacuum Pump and Burner Power depending on individual Thermostat status change (Figure 42).
 - b. **SRP Accu-Rate™ Digital Panel**
 - i. 1 Pump (Refer to LT230)
 - ii. 2 Pumps (Refer to LT231)
 - c. **SRP Accu-Rate™ Pro Panel** (Refer to manual LT235)
 - i. VE132-X-5 Modulating with Motorized Dampers
 - ii. VE132-X-6 Modulating with VFD

Burners

Maximum current draw is 0.2 A per burner. Burners internally operate on 24 VAC with a 120 VAC 60 Hz Power Cord and transformer provided. The Power Cord uses a standard single phase North American three-pronged plug (grounded) that is 3 ft. (90 cm) long and extends from the back of the Burner. Burner wiring between the transformer, gas valve, transformer etc. has been completed by the manufacturer as shown in the Figure 41. Wiring label is located on the burner service door.

Any repair/replacement of the manufacturer's wiring must have a minimum temperature rating of at least 105°C and supply circuit wiring shall have a minimum size of 18 AWG.




Figure 41. Burner Wiring Diagram

Fresh Air Blower Interlock

If a Blower is installed to achieve the 40 CFM per 100,000 BTU/hr. of Fresh (Combustion) Air Supply requirement then an 'interlock' connection must be made between the Blower and Vacuum Switch (and therefore the Vacuum Pump).

1. Mount the Vacuum Switch and make the connections to the Blower as required. (See Figure 42 below for details)
2. Ensure that field wiring maintains the required clearances when being routed near equipment.




Figure 42: Fresh Air Blower Connection Diagram

System Wiring Connections

1. Ensure that field wiring maintains the required clearances when being routed near equipment
2. Mount ALL Electrical components as required by Code(s) and Heating Zone system layout/plan.


Reminder: Ensure that all Electricity to the supply locations involved has been 'disconnected' and 'locked out' as per local and national safety requirements before proceeding with any part of the electrical installation.

3. Mount the Electrical Power Outlets (120 VAC, 60 Hz, 0.2 A) for each Burner. Outlets are required to be within reach of the Burner Power Cord while maintaining the minimum clearances around the equipment.
4. Mount the Thermostat(s) as per plan. Wire the Thermostats into the system. Sample control diagrams are shown in the following pages.
5. Wire the Electrical Power Outlets to the system control as required for the Heating Zone system layout/plan.
6. Mount/position the Vacuum Switch onto the Radiant System as shown in Figure 36. Connect the Vacuum Switch to the Vacuum Pump and the control system as shown in the sample diagrams in the following pages.
7. Connect the Electrical Power Supply to the control system as shown in the sample diagrams in the following pages.
8. Test all connections/wires as necessary.

DO NOT energize the Controls with Electrical Power until it is time to complete the COMMISSIONING of the System.

9. Confirm that the Vacuum Pump's impeller rotates in the same direction indicated by the arrow on the pump scroll. To reverse rotation, see instructions on the motor.

- Unguarded openings can entangle clothing and severe injury can result
- Unrestricted air flow into Vacuum Pump can cause the motor to overload






Figure 44: Control Panel Wiring Diagram (Optional)
Two Heating Zones, 24VAC Supplied to Burners




Figure 45: Control Panel Wiring Diagram (Optional)

Four Heating Zones, 24VAC Supplied to Burners, Single-Stage Fire Mode, Post-Purge Timer for Pump




Figure 46: Control Panel Wiring Diagram (Optional)
 Three Heating Zones, 24VAC Supplied to Burners, Single-Stage Fire Mode
 Fresh-Air Blower Relay Interlock, VFD for Pump and Post-Purge Timer for Pump




Figure 47: Control Panel Wiring Diagram (Optional)
Two Heating Zones with Two Pumps, 24VAC Supplied to Burners, Single-Stage Fire Mode
VFD for Pump and Post-Purge Timer for Pump

COMMISSIONING

1 - Installation Checklist

Before proceeding with the start-up of the system, review the list of items below to ensure proper operation.

- ☐ Close all Quick links and turnbuckles to avoid unlocking chain with inadvertent contact.
- ☐ Verify that the Burners are correct for the fuel being burned. The rating plate listing this information is located on the Burner housing, check this against your site plans.
- ☐ Burners are position dependent. For proper operation, ensure that the Burner labeled as 'No. 1' on the housing is located at the end of each Radiant Branch. Subsequent Burners in each Branch must be positioned sequentially.
- ☐ Burners should be mounted with the Burner casting as far back in the Tube opening as possible. Ensure that little or no Tube is in view through the viewing window.
- ☐ Ensure that the End Vent Cap is oriented with the ¼" test hole at the 12 o'clock position and that it has been secured to the end of each Branch with a #8 x 3/8" screw.
- ☐ Ensure that Tubes are fully inserted in the Couplings and tightened with band clamp hardware at the 10 or 2 o'clock position. Tighten band clamps alternately to prevent buckling of the Coupling sleeve.
- ☐ Ensure that each Branch has a Damper Coupling at the end of the Radiant length, as well as one at the Vacuum Pump. If the system is symmetrical, one Damper along the Common Tailpipe may be used. Single Rate Systems will use standard Manual Dampers while Modulating Rate Systems will use Motorized Dampers.
- ☐ Ensure that Reflectors are properly overlapped and that every second overlap joint is screwed together, as shown in Figure 9. The remaining joints are left loose. This will allow the Reflectors to 'telescope' with the thermal expansion of the System.
- ☐ Visually confirm that the Vacuum Pump's impeller rotates in the same direction indicated by the arrow on the pump scroll. To reverse the rotation, see instructions on the motor.
- ☐ Ensure that EACH Flexible Gas Connector is of sufficient size for the desired Burner rate and is installed in a smooth arc with no kinks.
- ☐ Purge Gas Lines according to installation codes
- ☐ Verify the Wiring and that the Electrical Power Supply is connected but remains turned OFF.

Refer to Figure 9 for Radiant Line System –Component Relationships

2 – Initial System Power Test

With the individual gas valves to each burner 'Shut off' perform the following:

1. Ensure Gas Supply is turned OFF. (Open main gas valve and ensure that no gas is flowing through the gas meter [dial test].)
2. Verify that lock-up gas pressure is not above 14 in. W.C.
3. Set all thermostats below room temperature and turn ON main power – no part of the System should be energized.
4. Check each Radiant Branch in each Zone in sequence by turning up the appropriate Thermostat. In each case the Vacuum Pump should turn on and after the pre-purge time, the Burners in that Zone should attempt to light.
5. Troubleshoot as necessary to get the System operational. (See the Trouble-Shooting section of this manual for more detailed information and helpful notes.)

3 – Cold Balancing the System Vacuum

NOTE: The Premier VS-VH burner is a variable rate appliance. Vacuum Pump setting must be accurately adjusted to ensure Burners are operating at the specified design input.

1. Turn ON the Electrical Supply but NOT the Gas Supply (remains turned OFF). You may also disconnect the air switch to allow for system cold balancing. This will let you start the vacuum pump without energizing any burners.
 2. Allow the system to run without Burners operating.
 3. With a manometer check the vacuum at the End Vent Cap of the longest Branch. (Refer to Figure 48 for manometer positioning details.)
 4. Adjust the Damper that is installed in the Tailpipe of the same Branch to obtain the vacuum readings according to Table G below. (In Systems that are "Symmetrical" there will be only one Damper along the Common Tailpipe.) A cold vacuum will always be higher than a hot vacuum, so compensation should be factored in for cold balancing as follows – add 0.40" W.C. for each burner in a zone. If your desired hot setting is 3.0" W.C. and you have two burners in a row in that zone, set your cold vacuum to $3.0" + 0.40" + 0.40" = 3.80"$ W.C. Mark the Damper positions for future reference.
 5. Proceed similarly until each individual branch in the system is balanced/adjusted.
- Shut down the System.

Refer to table G: Vacuum System Settings for Relative Burner Rates




Figure 48: Manometer Placement Diagram

Table G: Vacuum System Settings for Relative Burner Rates

Burner Model No.	Burner Operating Rate (BTU/hr)	Vacuum Setting (in. W.C.)	Maximum # of Burners per Branch	Gas Orifice Size
Premier VS-VH02	20,000	3	4	43
	12,000	1.7		
Premier VS-VH04	40,000	3	4	31
	24,000	1.7		
Premier VS-VH06	60,000	3	4	27
	36,000	1.7		
Premier VS-VH08	80,000	3	4	13
	48,000	1.7		
Premier VS-VH10	100,000	3	4	1
	60,000	1.7		
Premier VS-VH12	120,000	3.4	3	K
	110,000	3		
	66,000	1.7		

4 – Burner Time Delay Setting

1. Once you have acquired the proper cold start End Vent Vacuum, go to the burner closest to the vacuum pump on that branch.

NOTE: In most applications we would like to see the burner closest to the pump to start up first. If you have a system with only one burner in a branch, all you need to do is set the End Vent Vacuum and plug in the heater. No burner adjustment should be needed.

NOTE: Each module in each burner has 3 dip switches as seen in Figure 49 below.




Figure 49: Module Dip Switch Location

2. Set the dip switch settings of all burners to ensure at least 60 seconds delay between the consecutive burners. The modules all come set for 30 seconds, so the burner closest to the pump will not need to be changed, (for a 3-burner branch, set Burner #3 for 30 seconds, Burner #2 for 90 seconds, and Burner #1 for 150 seconds). Refer to Table H for dip switch settings and timing.

Table H: Dip Switch Settings

	Switch 1	Switch 2	Switch 3
30 sec	OFF	OFF	OFF
60 sec	OFF	ON	OFF
90 sec	ON	ON	OFF
120 sec	OFF	OFF	ON
150 sec	ON	OFF	ON
180 sec	OFF	ON	ON
240 sec	ON	ON	ON

5 – Burner adjustment

1. Now we are ready to start up the burner. Before plugging in the burner, take the cap off the Maxitrol Zero Regulator. Refer to Figure 50 below to locate Zero Regulator.




Figure 50: Maxitrol Zero Regulator

NOTE: The Maxitrol Zero Regulator takes the incoming gas pressure and reduces it down to zero. The gas valve is set to a specific setting so that it acts mostly just like a gate valve, open and closed. The gas pressure is knocked down to zero, the gas valve opens and the vacuum sucks in the amount of fuel it needs. You never want to adjust the gas valve. We make all fuel adjustments with the Zero Regulator **ONLY**.

NOTE: These burners are at their optimum performance when they are **burning their leanest** (least amount of fuel possible but still lit). When they are running rich they can make high pitch harmonic noises.

2. The zero regulators come factory set as shown in Figure 51. Make sure the one you are working on has not been tampered or set incorrectly.
3. Make sure the gas supply line has been purged then plug in the burner to the main 115V supply.

NOTE: Once plugged in, the burner will wait the 30 seconds that is set from the dip switch and then try to light. In some conditions the burner will light, some may not light, and some may light intermittently.




Figure 51: Adjustment Screw Starting Position




Figure 52: Adjustment of Maxitrol Zero Regulator

4. If your burner will not stay lit or will intermittently light you may need to adjust the Zero Regulator. Refer to Figure 52 and the following sequence.

NOTE: The Honeywell gas valve is screwed into a square mixing chamber as seen in Figure 52. On the opposite side of the mixing chamber our air plate is screwed on.

- a. Take a firm object (cardboard or metal strip) and when it starts to spark, carefully slide the object over the opening slowly reducing the air being drafted in.
 - b. When the flame stabilizes keep the opening restricted that amount. If the adjustment screw was at the correct starting position you should not have to restrict a big amount of the opening.
 - c. Adjust the Zero Regulator adjustment screw. Clockwise increases the amount of fuel being supplied to the burner and counterclockwise will reduce fuel supply.
 - d. Turn the adjustment screw a 1/4 - 1/2 turn clockwise. Wait 2 – 5 seconds to allow the diaphragm in the regulator to adjust. The flame should get stronger.
 - e. Now slowly slide your object back to allow more air in. Just when the flame starts to get unstable again (flutter and intermittent sparking due to loss of flame signal) turn the adjustment screw another 1/4 – 1/2 turn clockwise.
 - f. Repeat these steps until you are able to completely remove your object and allow full air draw and a nice stable flame is present. We need to make sure this is as lean as possible.
 - g. Now that the burner is up and running, turn the adjustment screw a 1/4 turn counterclockwise. After every 1/4 turn wait 5 seconds to allow it to settle. Keep turning it a 1/4 turn at a time with the pauses in between until the flame once again becomes unstable.
 - h. Now once it starts fluttering and sparking, turn the screw a 1/2 turn clockwise. This will stabilize the flame. Now we are sure it is a strong stable flame operating at its leanest.
 - i. Just to make sure it is operating properly; the flame sensor should be glowing red. Leave this burner running.
5. Now go to the next burner in line moving away from the burner and repeat all steps. Make sure you adjust the dip switch settings so this one will not light at the same time as the others.

NOTE: All burners need adjustment **EXCEPT** burner #1's. Those are the burners furthest away from the vacuum pump and closest to the End Vent Cap. Burner #1's uses fresh air for secondary combustion, so it is very forgiving. The flame characteristics on this burner are also different from the rest. You will still have to set the dip switch setting on the burner.

Now your burners are running, wait 1/2 hour with the system heating. Now we can adjust the End Vent Vacuum to get the proper vacuum designed for your system.

6 – Final Balancing the System Vacuum

1. Turn ON the Gas Supply.
2. Turn up the Thermostat(s) to start the System and let it run (with Burners operating) for at least 30 minutes.
3. With a manometer check the vacuum at the End Vent Cap of the longest Branch. (Refer to Figure 48 for manometer positioning details.)
4. Adjust the Dampers again (**Caution: dampers are now hot adjust with caution**) as required to obtain the vacuum readings within +0.1 to -0.2 in. W.C. of the settings in Table F. The Burners in this Branch should now be firing at the appropriate rate.
5. Proceed similarly until each individual Branch in the System is balanced/re-adjusted.
6. Mark the Damper position and lock in place when the System has been balanced. (Lock in place by putting a screw through the handle to hold it against the Sleeve/Tube.)
7. Turn the Thermostat(s) down again to shut off the System.

NOTE: An End Vent Vacuum which is intermediate to (between) those shown will result in rates intermediate and proportional to those which are listed.

NOTE: Vacuum settings and rates apply regardless of the number of Burners being used in the system branch to the maximum allowable number of burners as per Table G.

OPERATION

Manual Set-Up

1. Set the ambient temperature to be maintained by each Thermostat.
2. Ensure Electrical Power and Gas Supply are turned "ON"

Automatic Operating Sequence

Start-up

1. Thermostat calls for heat and energizes the transformer relay.
2. Transformer relay contacts close and the Vacuum Pump motor is energized.
3. If the Vacuum Switch finds no fault, power is supplied to all the Burners in the Zone(s) in which the Thermostat(s) are calling for heat.
4. At the Burner, the control module waits for the pre-purge period and then opens the fuel valve and the spark igniter is energized. Time delay in the control module causes the Burners to light sequentially.
5. When the flame is established, the flame sensor signal returns to the control module and the ignition spark ceases.
6. If the flame is not established, the control module will re-try the ignition cycle again in 30 seconds.
7. Should ignition continue to fail, the control module will make 3 ignition attempts every hour.
8. If it does not, or if it continues to "not establish a flame", Trouble-Shoot to find the cause.
9. System operates until Thermostat(s) temperature setting is reached.

Shut Down

1. When the Thermostat has been supplied sufficient heat, its contacts open and de-energize the transformer relay.
2. The contacts of the transformer relay open and Electrical Power to the Burners and Vacuum Pump is disconnected.
3. A post purge cycle can be provided when a Control Panel is supplied.
4. System remains 'OFF' until ambient temperature falls below the Thermostat(s) setting.
5. System cycles through Steps 1 to 9 on a continuous basis until Power is turned OFF.

MAINTENANCE

General Safety Reminders

- Ensure Gas Supply and Electrical Power are shut OFF before commencing maintenance work. *Exception: Checking ignitor flames will require the system to be operational.*
- Keep area clear and free from combustible materials, gasoline and other flammable vapors and liquids.
- **Caution:** Label all wires prior to disconnection when servicing controls. Wiring Errors can cause improper and dangerous operation.
- **Verify proper operation and set-up (as listed in the Commissioning section) after servicing.**

Annual Maintenance Recommendations

Annual maintenance, **prior to** the heating season (Fall/Winter) is recommended.

The System

1. Inspect the Common Tailpipe and Vent Pipe for soot or dirt, clean as required to avoid obstructions.
2. Check that Flexible Boot Connectors are without cracks, kinks or leaking connections. Change the Connectors every three to four years.
3. Ensure that the Vacuum Pump and motor mounting bolts are tight.
4. Make a visual inspection (without dismounting) of the Vacuum Pump impeller.
5. Inspect the Vacuum Switch connections.
6. Clean the Condensate Trap and ensure that all piping to / from the Condensate Trap allows free flow of fluid.
7. Make spot checks of the interior of the Radiant Line Tubes for soot or obstructions, clean as required.
8. Re-align reflectors and supports as needed.

Each Burner

1. Remove Burner and inspect burner face for soot or cracks. Burner face should be back flushed with air every year, to clean the internal ceramic burner.
2. Visually inspect electrode. Replace if there is excessive oxidation, erosion or cracks in the ceramic insulators. Set spark gap at 0.125" (3.2 mm) and clean the electrodes.
3. Verify that flame observation glass is clean, free of cracks and airtight.
4. Inspect air filter. Change as necessary – frequency is dependent on the environment.

NOTE: Dirty air filters will restrict combustion air flow into the burner housing, creating a slight negative pressure environment for the zero governor (and other controls). Consequently, while flame characteristics and balance will not change appreciably, overall burner rate will decline. Very dirty filters will cause the flame to become more rich (yellow and soft). Filters can be cleaned once with reverse air pressure, but it is generally more cost effective to merely replace them.

- For VS-VH Air Filter includes frame (Bulk Qty. 20) use part No.VH001B
- For VS-VH Filter Media Kits (Bulk Qty 24) use part No.VH053B

Adjust the System

1. Turn on gas and electric power.
2. Start system and allow to run for 30 minutes.
3. Verify end plate vacuum settings against Installation/Operation Manual, to establish correct burner rates with a manometer. Check the vacuum at the End Vent Cap of the longest Branch. (Refer to Figure 48 for manometer positioning details.)

- If the Vacuum is too low, inspect the Flexible Boot Connectors on the Inlet and Outlet of the Vacuum Pump for tight connections, leaks, damage, kinks, etc.
 - To adjust the vacuum on a single leg, manipulate the damper coupling at the end of that leg.
 - To adjust the vacuum on the entire system, manipulate the damper coupling at the vacuum pump.
4. There should be no sound of leaking air around any of the various gaskets or connections.

Burner adjustment

1. Observe each flame through the flame sight glass.
 - Flame may flutter once or twice at ignition but should settle promptly.
 - Flame should extend straight out from Ignitor
 - Sense rod (and ignitor) will glow bright red/orange.
2. End burners (No. 1, or the furthest upstream from vacuum pump) do not need to be adjusted. The flame in a No. 1 burner, it is solid blue in colour.
3. All downstream burners (Nos. 2 - 4) may require adjustment of the Maxitrol regulator located inside each VS burner; refer to Burner Adjustment under Commissioning Chapter.
4. VS-VH systems with multiple in-series burners can occasionally produce a high-pitched noise that can be best be described as a whistle, or howl. Usually the howl is produced by a rich no. 2 burner. De-tune the burner by slowly reducing the gas pressure at the internal Maxitrol regulator in the burner. You may also have to de-tune the no. 3 burner. Turn down the pressure till the noise disappears. Reducing it too much may cause ignition problems later.

Vacuum Pump

Vacuum Pump Fails to Run

1. Check that a Thermostat is calling for heat.
2. Check the main Electrical Power Supply, fuses or breakers.
3. Check for power to the Control Panel or Relay.

Vacuum Pump Runs, But Little to No Vacuum

1. Check the direction of the impeller rotation.
2. Are the End Vent Caps installed in all the Branches?

Vacuum Pump Runs, But No Power to Burners

1. Check the Vacuum Switch.
2. Check voltage to Burner terminals.
3. Check Relay.
4. Check individual Burner control.

Burners

No Power to Burner

1. Check if correct Thermostat is calling for heat.
2. Check for 120VAC supply at Burner.

No Gas Supply

1. Ensure manual supply valve to the System is turned ON.
2. Ensure gas valve knob on Burner gas control is ON.
3. Check for 24V across valve terminals during ignition trial time.

Burner Does Not Light

1. Ensure spark is present during ignition trial.
2. (If no, check control module, check for cracked ignitor insulation.)
3. Ensure there is gas flow during ignition trial.
4. Purge gas lines.
5. Ensure Filter is not obstructed.

Burner Does Not Stay Lit

1. Check ground wire from ignitor for continuity.
2. Measure flame signal current, it should be above 5uA - DC.
3. Regulator adjustment may be necessary.
4. Ensure Filter is not obstructed.

PARTS

Table I: Burner Parts List

Item No.	Part No.	Description
1	VG010	ZERO GOVERNOR, MAXITROL R-500Z
2	VG009	GAS VALVE, HONEYWELL 8205M
3	VH002	VALVE GASKET
4	(See Table D)	AIR PLATE
5	VS022	COMBUSTION AIR ADAPTOR & GASKET (AIR)
6	VH001	COMBUSTION AIR FILTER
7	VG001	MIXING CHAMBER
8	CH007	VALVE TRAIN GASKET/BURNER MOUNT
9	CE008	TRANSFORMER
10	CE056	CONTROL MODULE, FENWAL
11	CE010	POWER CORD
12	CE057	OPERATOR INDICATOR LIGHT (ROUND)
13	VH003	BURNER MOUNTING GASKET
14	VH004	MOUNTING U-BOLTS
15	CE036	SENSE WIRE </td
16	CE006	IGNITION WIRE (13 INCH)
17	VE002	ELECTRODE ASS'Y
18	VH005	ELECTRODE ASS'Y GASKET
19	CH011	FLAME SIGHT WINDOW
20	VG026	BURNER CASTING ASS'Y VS Under 150,000 (ELECTRODE INCL)
	CE173	RELAY G2R-1-S-AC24(S)




Table J: Main System Component Parts List

Part No.	Description	Part No.	Description
COMMON COMPONENTS		Coated Tubes	
VT001	VS-VH COMBUSTION TUBE, 4" OD	CT032	TUBE, 4" OD, COATED INSIDE ONLY
CT001	TUBE, 4" OD, HEAT TREATED ALUM.	CT033	TUBE, 4" OD, COATED IN & OUT
CT010	ELBOW, 90 DEG, 4" OD	VT004	COMBUSTION TUBE, VS-VH, COATED IN
CT020	U-TUBE, 4" OD	VT005	COMB TUBE, VS-VH, COAT IN & OUT
CR010	COUPLING ASS'Y 4" OD ALUM	CT034	ELBOW, 90 DEG, 4" OD, COATED IN
VS016	END VENT CAP	CT035	ELBOW, 90 DEG, 4" OD, COATED IN & OUT
CH010	TURNBUCKLE	CT036	TEE, 4" OD, SQUARE, COATED IN
CR003	HANGER, TUBE & REFLECTOR	CT037	TEE, 4" OD, SQUARE, COATED IN & OUT
CR024	REFL. BRACKET & CLIP SET	5" Tailpipe	
CR001	REFLECTOR 124"	CT038	TUBE, 5" OD
CR002	END CAP	CT040	ELBOW, 90 DEG, 5" OD
CS005	4" AIR INLET HOOD	CT110	ELBOW, 45 DEG, 5" OD
CR015	DAMPER COUPLING, 4" OD, MANUAL	CT052	TEE, 5" OD, SINGLE SWEPT
CR025	HANGER STRAP, 4" OD, TAILPIPE	CT039	TEE, 5" OD, DOUBLE SWEPT
VH044	CONDENSATE TRAP ASS'Y	CT056	CROSS, 5" OD, SQUARE
SPECIALTY TUBING COMPONENTS		CT078	CROSS, 5" OD, DOUBLE SWEPT
CT002	TUBE, 4" OD, HR	CR068	COUPLING ASS'Y 5" OD
CT012	TUBE, 4" OD ALUM NHT	CR070	DAMPER COUPLING, 5" OD, MANUAL
VT001S	SHORT COMBUSTION TUBE, VS-VH	CR029	HANGER STRAP, 5" OD, TAILPIPE
CT055	ELBOW, 45 DEG, 4" OD	CT042	REDUCER, 5" TO 4" OD, ALUM
CT050	TEE, 4" OD, DOUBLE SWEPT	6" Tailpipe	
CT051	TEE, 4" OD, SINGLE SWEPT	CT145	TUBE, 6" OD
CT022	CROSS, 4" OD, SQUARE	CT147	ELBOW, 90 DEG, 6" OD
CT109	CROSS, 4" OD, DOUBLE SWEPT	CT152	ELBOW, 45 DEG, 6" OD
Stainless Steel (S/S)		CT149	TEE, 6" OD, SINGLE SWEPT
VT003	S/S COMBUSTION TUBE VS-VH, 4" OD	CT146	TEE, 6" OD, DOUBLE SWEPT
CT030	S/S RADIANT TUBE, 4" OD	CT150	CROSS, 6" OD, DOUBLE SWEPT
CR005	S/S COUPLING ASS'Y, 4" OD	CR166	COUPLING ASS'Y 6" OD
CR027	S/S COUPLING LINER	CR170	HANGER STRAP, 6" OD, TAILPIPE
CR047	S/S DAMPER COUPLING, 4" OD, MANUAL	VT006	REDUCER, 6" TO 4" OD, ALUM
CR032	S/S REFLECTOR, 124"	CT151	REDUCER, 6" TO 5" OD, ALUM
CR033	S/S SIDE REFLECTOR		

Table K: Vacuum Pump and Optional Equipment Parts List

Part No.	Description	Part No.	Description
VACUUM PUMPS		OPTIONAL EQUIPMENT	
VH010	PUMP MOUNTING PKG.	Miter Reflector Components	
VS010	VIBRATION BOOT PKG - 4" for vacuum pump	CR039	REFLECTOR KIT, MITERED, 90 DEG
VS048	VIBRATION BOOT PKG - 6" for vacuum pump	VR003	BURNER REFLECTOR KIT
VE020	VACUUM PUMP PKG "A" w/ below:	Side Reflector Components	
	VE032 MOTOR - 0.75 HP, 115/230 V, 1 PH	CR019	SIDE REFLECTOR"
VE024	VACUUM PUMP PKG "A" w/ below:	CR016	BRACKET ASS'Y, SIDE SHIELD
	VE039 MOTOR - 0.75 HP, 208/230/460 V, 3 PH	CR035	RETAINER CLIP, SIDE SHIELD
VE021	VACUUM PUMP PKG "B" w/ below:	Bottom Shield Components	
	VE030 MOTOR - 1.50 HP, 208/230/460V, 3 PH	CR018	BOTTOM SHIELD
VE023	VACUUM PUMP PKG "B" w/ below:	CR017	SUPPORT ASS'Y, BOTTOM SHIELD
	VE031 MOTOR - 1.50 HP, 575 V, 3 PH	DECO-GRILLE Components (Suspended Heater)	
VE025	VACUUM PUMP PKG "B" w/ below:	CR051	DECO-GRILLE, 15" x 60" x 0.5"
	VE049 MOTOR - 1.50 HP, 115/230 V, 1 PH	CR052	DECO-GRILLE SUPPORT, 60"
PUMP ADAPTOR KITS		CR053	DECO-GRILLE CROSS STRAP, 15"
CT155*	4" TO 6" PUMP ADAPTOR KIT w/ below:	CR054	DECO-GRILL END ANGLE, 15"
	CT048 REDUCER W/ PS NIPPLE, 6" TO 4" OD	DECO-GRILLE Components (Suspended Ceiling)	
	CR046 CLAMP, 4" OD	CR026	DECO-GRILLE PANEL, 24" x 48"
CT156	5" TO 6" PUMP ADAPTOR KIT w/ below:	CS059	DECO-GRILLE SIDE SHIELD
	CT041 REDUCER W/ PS NIPPLE, 6" TO 5" OD	CR053	DECO-GRILLE CROSS STRAP. 15"
	CR068 CLAMP, 5" OD	CR054	DECO-GRILLE END ANGLE, 15"
CT157	6" TO 6" PUMP ADAPTOR KIT w/ below:	CS027	T-BAR SHIELD
	CT148CONNECTOR W/ PS NIPPLE, 6" OD	WALL VENT TERMINAL	
	CR166 CLAMP, 6" OD	CT011	VENT TERMINAL 4" - Exterior Wall Flue)
		CT044	VENT TERMINAL 6" - Exterior Wall Flue
		CS006	WALL THIMBLE 4" (Pump A)
		CS033	WALL THIMBLE 6" (Pump B)

*Note: Included in all A and B Pump packages.

Table L: Gas Connection Replacement Part Numbers

Part No.	Description USA	Canada
CG022	GAS FLEX CONNECTOR - 36" x 1/2" dia.	CAN part No. CG052 – 30"
CG011	SHUT OFF VALVE - for gas flex (1/2")	

Table M: Burner Part Numbers

Part No.	Description
VH02N-1	PREMIER VS-VH BURNER, 20,000 BTU, NAT
VH02N-2	PREMIER VS-VH BURNER, 20,000 BTU, NAT
VH02N-3	PREMIER VS-VH BURNER, 20,000 BTU, NAT
VH02N-4	PREMIER VS-VH BURNER, 20,000 BTU, NAT
VH04N-1	PREMIER VS-VH BURNER, 40,000 BTU, NAT
VH04N-2	PREMIER VS-VH BURNER, 40,000 BTU, NAT
VH04N-3	PREMIER VS-VH BURNER, 40,000 BTU, NAT
VH04N-4	PREMIER VS-VH BURNER, 40,000 BTU, NAT
VH06N-1	PREMIER VS-VH BURNER, 60,000 BTU, NAT
VH06N-2	PREMIER VS-VH BURNER, 60,000 BTU, NAT
VH06N-3	PREMIER VS-VH BURNER, 60,000 BTU, NAT
VH06N-4	PREMIER VS-VH BURNER, 60,000 BTU, NAT
VH08N-1	PREMIER VS-VH BURNER, 80,000 BTU, NAT
VH08N-2	PREMIER VS-VH BURNER, 80,000 BTU, NAT
VH08N-3	PREMIER VS-VH BURNER, 80,000 BTU, NAT
VH08N-4	PREMIER VS-VH BURNER, 80,000 BTU, NAT
VH10N-1	PREMIER VS-VH BURNER, 100,000 BTU, NAT
VH10N-2	PREMIER VS-VH BURNER, 100,000 BTU, NAT
VH10N-3	PREMIER VS-VH BURNER, 100,000 BTU, NAT
VH10N-4	PREMIER VS-VH BURNER, 100,000 BTU, NAT
VH12N-1	PREMIER VS-VH BURNER, 120,000 BTU, NAT
VH12N-2	PREMIER VS-VH BURNER, 120,000 BTU, NAT
VH12N-3	PREMIER VS-VH BURNER, 120,000 BTU, NAT

WARRANTY

PREMIER VS-VH VACUUM SERIES INFRARED SYSTEM

The Manufacturer warrants to the original owner that the product will be free of defects in material and workmanship as described below.

VS-VH Vacuum System Components	Warranty Period (Years)				
	1	3	5	7	10
Control Panel	x				
Vacuum Pump		x			
Burner Electrical Components		x			
Cast Iron Burner Head					x
Hot Rolled Heat Exchanger			x		
Aluminized Heat Exchanger				x	
Hot Rolled Heat Exchanger with Control Panel				x	
Aluminized Heat Exchanger with Control Panel					x
Tailpipe – Aluminized / Coated (per minimum design length)					x

The Manufacturer's obligation under this warranty is limited to repair or replacement, F.O.B. its facility, of the defective part. In the case of replacement parts, the warranty period shall be the longer of the original warranty or a period of 12 months from date of purchase. In no event shall the manufacturer be liable for incidental expense or consequential damages of any kind.

This warranty does not cover any shipping, installation or other labour costs incurred in the repair or replacement of the product. No materials will be accepted for return without authorization.

This warranty will not apply, if in the judgment of the Manufacturer, the equipment has been improperly installed, unreasonably used, damaged, or modified.

This warranty will not apply to damage to the product when used in corrosive atmospheres and in particular atmospheres containing halogenated hydrocarbons. No person is authorized to assume for the Manufacturer any other warranty, obligation or liability.

THE REMEDIES PROVIDED FOR IN THE ABOVE EXPRESS WARRANTIES ARE THE SOLE AND EXCLUSIVE REMEDIES. NO OTHER EXPRESS OR IMPLIED WARRANTIES ARE MADE INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE OR PURPOSE.