



DIVERSIFIED

DuraDrive Wiring Diagram

Voltage is labeled on relay set, motor, and gear.
For 3 phase use 220V to contactors

